



Toll Free: 87 PERMATEX  
(877-376-2839)

10 Columbus Blvd., Hartford,  
Connecticut 06106

6875 Parkland Boulevard, Solon  
Ohio 44139

## Technical Data Sheet

### Permatex® Windshield Repair

AAM Revised 03/14

#### PRODUCT DESCRIPTION

Permatex® Windshield Repair makes repairs to most types of damaged laminated windshield glass; including bullseyes and star damage in just a few minutes. This kit includes the liquid resin, repair syringe and plunger, adhesive disc, pedestal, curing strip and instruction sheet. No mixing is required and it cures by natural daylight.

**Note: This product is not recommended for repairing linear windshield cracks.**

#### PRODUCT BENEFITS

- Easy to use
- Easy to follow step by step instructions
- Fast curing
- Repairs bullseyes and star damage

#### TYPICAL APPLICATIONS

- Repairs bullseyes and star damage in laminated automotive windshields

#### DIRECTIONS FOR USE

##### For Bullseye and Star Damage

Perform repairs in a shaded area with the windshield temperatures between 50°F and 75°F. CAUTION: Do not allow the resin in the syringe to come into contact with the car's finish as this may cause damage. A safety razor and push pin are required to remove components and finish repair.

1. Clean out any loose glass particles from PIT (hole caused by striking object) of the break using push pin or needle. Clean the area surrounding the break using a dry cloth or paper towel.
2. Peel backing off one side of adhesive seal. Line up hole in seal with PIT (tab pointing upward). Press seal to glass. Run fingers around seal to insure a tight bond.
3. Peel backing from TOP side of adhesive.
4. Line up the pedestal with the adhesive seal making sure tabs match up. Press the pedestal to seal. Run fingers around pedestal to insure a tight bond.
5. Cut tip off resin container (about 1/8 inch) to open stem. Place stem 1/4 inch into pedestal opening. Slowly squeeze resin tube, releasing resin into the pedestal. Continue squeezing resin tube and remove from pedestal. Wipe any excess resin from tip with cloth and save empty container for Step 10.
6. Press fit injector into pedestal. Insure that the connection is tight.
7. Hold injector in one hand, pull plunger upward with the other hand. Lock plunger by ENGAGING LOWER notch in plunger with spring clip. Release hands and allow device to remain in locked position. LET SIT

FOR 10 MINUTES then proceed to Step 8.

8. Remove injector from pedestal momentarily (to let air in). Replace injector as in Step 6. DEPRESS plunger downward and ENGAGE UPPER notch with spring clip. LET SIT FOR A MINIMUM OF 20 MINUTES then proceed to Step 9.
9. Remove injector and discard. Loosen the outer edges of pedestal with safety razor. Once top part of pedestal and seal is bent away from the glass, grip the pedestal tab and SLOWLY pull tab away. Wipe and remove excess resin.
10. Hold resin container in one hand and make ready the clear yellow curing film in the other hand. Slowly squeeze the resin container applying a drop of resin into the PIT. Place the clear yellow curing film over the PIT holding resin in the PIT.
11. Run safety razor lightly over the clear yellow film to vent out any air bubbles. NOTE: Ultra violet sun rays cure the resin. Park vehicle in direct sunlight for 15 minutes. (On hazy days, park vehicle outside for a minimum of 1 hour).
12. Once resin has cured, carefully remove curing strip by peeling it away from windshield.  
FINISHING TIPS: If the surface of the glass is uneven, a safety razor may be used to remove any excess cured resin from windshield. Clean windshield with glass cleaner or alcohol.

#### For Cleanup

1. Wipe up any excess resin with a clean cloth or paper towel.
2. Cured resin must be scraped off windshield with safety razor.
3. Clean hands with Fast Orange® hand cleaner.

#### PHYSICAL PROPERTIES

	Typical Value
Chemical Type	Acrylic Resin
Appearance	Clear resin
Odor	Mild
Specific Gravity	1.02
Flash Point, TCC	>150°F

#### GENERAL INFORMATION

**This product is not recommended for use in pure oxygen and/or oxygen rich systems and should not be selected for use with chlorine or other strong oxidizing materials.**

**For safe handling information on this product, consult the Material Safety Data Sheet, (MSDS).**

NOT FOR PRODUCT SPECIFICATIONS.

THE TECHNICAL DATA CONTAINED HEREIN ARE INTENDED AS REFERENCE ONLY.

PLEASE CONTACT PERMATEX, INC., TECHNICAL SERVICE DEPARTMENT FOR ASSISTANCE AND RECOMMENDATIONS FOR YOUR SPECIFIC APPLICATION.  
PERMATEX, INC., HARTFORD SQUARE NORTH, 10 COLUMBUS BOULEVARD, HARTFORD, CT 06106 PHONE - (1-877PERMATEX)

**ORDERING INFORMATION**

Part Number	Container Size
16067	0.025 fl. oz. syringe, carded

**STORAGE**

Products shall be ideally stored in a cool, dry location in unopened containers at a temperature between 8° and 28°C (46° and 82°F) unless otherwise labeled. Optimal storage is at the lower half of this temperature range. To prevent contamination of unused product, do not return any material to its original container.

**NOTE**

The data contained herein are furnished for information only and are believed to be reliable. We cannot assume responsibility for the results obtained by others over whose methods we have no control. **ITW Permatex, Inc. specifically disclaims all warranties expressed or implied, including warranties of merchantability or fitness for a particular purpose, arising from sale or use of Permatex, Inc. products and disclaims any liability for consequential or incidental damages of any kind, including lost profits.** This product may be covered by one or more United States or foreign patents or patent applications.